SERVICE CONTRACTS PERFORMANCE



The Renault Trucks 'Performance' contract takes away the burden of unforeseen and costly repairs.

Like the 'Reference' contract the 'Performance' package includes regularly scheduled inspections, by skilled Renault Trucks Technicians, to help prevent any long term issues with your vehicle. However, if the worst should happen and a repair is required on the driveline to keep your truck on the road and up to standard, then you're covered.

All repairs will be tailored to match your vehicles specific operating conditions and its **driveline*** will be maintained and repaired using only Genuine Renault Trucks Parts and Lubricants.

Payments are a fixed monthly rate so that all maintenance and repair expenditure is easily trackable.

PERFORMANCE SERVICE CONTRACT – KEY BENEFITS



- Plan your inspections well in advance
- Protect your O-License and OCRS score
- Ensure your vehicles and drivers are safe and compliant
- Understand your costs with equal and fixed monthly payments
- Keep your vehicles out on the road
- Vehicles under this plan receive regular maintenance check ups
- Repairs for your driveline are covered

PERFORMANCE MAXI - A performance contract with repairs to chassis and cab also included!

The Performance Maxi Contract is an extended version of the Performance Contract providing repair and maintenance to not only the driveline but also the chassis and cab. This means that everything on the vehicle is covered for repair and maintenance excluding wearing parts – e.g. Brake Pads and clutch plates.

*Would you prefer a full Repair and Maintenance Contract? – try Excellence!

Find out more about all of our service contracts: Talk to your local dealer or visit **renault-trucks.co.uk**





PREVENTIVE MAINTENANCE (as per pre-agreed service schedule)

ROUTINE SERVICE

- Engine oil change oil and fuel filters change
- Gearbox oil and filter change
- Coolant replacement Particle filter maintenance
- Axle oil change
- Air conditioning maintenance & filter change
- Air filter change
- Air dryer change Fuel tanks water purge Water presence in compressed air tanks check by bleeding
- Power steering tank filter change
- Belts and tensioners replacement
- Fifth wheel or towing hook greasing
- Chassis and hinge lubrication Radiator cleaning Valve and injector clearance
- Level of screen wash, clutch fluid, coolant, engine and
- Mathy contents of the state of

- **ELECTRONIC CHECK**
- Dashboard instruments, warning lights and indicator
- Lighting condition Fixing condition and connection of batteries
- Master switch operation
- Fault codes, multifunction information display

BRAKE CHECK

- Braking system
- Brake pads wear, brake lever Parking brake operation

DRIVELINE CHECK

- Engine noise and smoke emission
- Radiator cores cleanliness Cooling circuit degree of
- protection
- Engine for leakage Intake circuit for leakage Axles for leakage Gearbox for leakage
- - Engine and radiator rubber mountings condition and tightening
 - Gearbox rubber mountings condition and tightening
 - Clutch wear
 - tightening

REPAIRS - PERFORMANCE

DRIVELINE

- Engine gaskets Cvlinder block, crankcase. connecting rods and bearings crankshaft, pistons, flywheel, damper, cylinder head, distribution, valves, camshaft, manifold, breather, turbo charger
- Water pump Thermostat Water/oil heat exchanger -
- Engine fan control Engine oil pump, oil filter
- housing and gauge Injection pump Feed pump Fuel filter housing

Steering wheel, housing and

- Electronic control unit
- Injectors and pipes

connecting rods

REPAIRS - PERFORMANCE MAXI

CHASSIS and CAB

Intercooler

Vacuum pump

Voltage regulator

Engine and gearbox

Oil circuit

Fuel circuit – Pipes – Fuel

Alternator - Starter motor -

suspension mounts Clutch fork – Clutch servo

Clutch, gearbox, suspensions

Power take off control

- Engine stop control and AdBlue tanks – Gauges Power steering – Hydraulic Water coolant circuit -
- pump Radiators – Exchangers – Hoses – Expansion tank.
- . Suspensions Shock absorbers - Cushions - Bars Air circuit - Fan - Air dryer -Battery box – Tool locker
 - Spare wheel carrier
 - Towing hook and coupling Fifth wheel , fifth wheel bed and mountings
 - Engine exhaust Silencer - SCR – DPF (except maintenance) – Pressure and
 - Heat sensor- Injector Accelerator pedal - Speed
 - limiter
 - Axles Stub axle Hubs and

- wheel bearing Bump stops Mechanic, pneumatic or hydraulic brakes control –
- Cylinders Pneumatic systems - Pipes Compressed air tanks – APM – EACU
- Complete chassis Lift axle system
- Cab structure Doors, door handles, locks
- (except barrel), hinges Fan and intakes
- Heating Demisting -Standalone heating Air conditioning – Climate
- Dashboard Consoles Coat
- hanger Storage

- Sun visor
 Seat belts
 Fridge
 Seats and Seat belts
 - - Seats and bunk mechanism Mounting, suspensions and
 - tilt of cab Master switch
 - Wiring harness and fixings All ECU's and switches –
 - Sensors Immobilizer Relays Horn Signaling lights

 - Wash/wipe mechanism and control
 - Radio and speakers Dashboard instruments -
 - Tachograph Controls Stalk switch Warning lights

OPTIONS EXAMPLES

- Collection and delivery of the vehicle for routine servicing Tvres
- Maintenance (Servicing) of Tail lift

renault-trucks.co.uk



lin

General terms and conditions apply.

- Shafts and gears of power take-off
- Differential Shafts

Rear underrun bar and

bumpers
 Step wells, side skirts and mud flaps condition

Seat belts, horn, screen

Air conditioning and heating

Wiper blades condition Cab mounting, rotation and unlocking system operation

Fuel and AdBlue tanks for

General condition and

Hydraulic retarder for

mounting of exhaust line

Power take off for leakage

Presence and mounting of noise shields

Hydraulic circuit and gear

Air gap check and axial play of electric retarder bearing

Hoses, ducts and pipes

Dynamic test of brakes, speed limiter, gearbox, clutch and steering

shift for leakage

condition

Fuel tank venting

wipers and washers

operation

OTHER CHECKS

leakage

system

leakage

- Exhaust brake
- Transfer box
- Rear axle Hubs reduction -
- Transmissions
- Electrical/hydraulic retarder
- Gearshift control
- Air compressor Gearbox: gearbox housing, synchronizers, pinions,

Transmission play Belts and tensioners

Air suspensions

and condition

AXLE / STEERING / CHASSIS CHECK

fixings support

bars condition

CAB CHECK

condition

SUSPENSIONS / WHEELS

Pneumatic suspension and remote control operation

Shock absorbers mounting

General condition of wiring

Springs, pads and stabilizer

Steering mechanism and front hub bearing

Chassis frame and cross-

members conditions

Locks and remote control

mirrors condition

operation General condition of cab

radiator grill and lights

Windscreen and rear-view

Front bumper, license plates,

condition

CHECK

shafts, relays, oil pump sensors Power take-off